

A--A0EB	KME CM88S-M PIN	A--AOEGA	KME PIN	A014A	KME CM86 FEEDER PIN	MCD-0022	FUJI PIN
	J01		J01		A02		
MCA-0222	FUJI PIN	MCA-0361	FUJI PIN	BFCB--0141	FUJI PIN	A--BFCG-0151	FUJI PIN
	OWN		OWN				OWN
A--1020806015	PIN	MCB-0022	FUJI PIN	GPC-0062	FUJI FEEDER PIN	AOCOC PIN	FUJI PIN M3
			OWN				M3
A--A01CA	FUJI PIN	GPC-0162	FUJI RETAINER PIN GPC-0162	A--GPH1795	PIN	A--1020806018	PIN
	A02						